






T300, NEW FIRMWARE VERSION IS AVAILABLE




* If a new update is available, once downloaded, the Wi-Fi signal (%) icon alternates with the text "OTA" and after about 3 minutes a notification is displayed; by pressing the key  or , the OTA AVAILABLE page is displayed.




Push the button 




Select CONFIRM and then push 

*** During the update, the display switches off and the keys flash alternately for approximately 2–3 minutes



** In case of selecting CANCEL the update, it will be possible to perform the update the T300 later by the menu CHECK FOR UPDATES. The updates will be possible only if the initial firmware version is equal or higher than R2.04.



**** If the update is not interrupted and completes successfully, the indication shown in point 8 is displayed; pressing any key returns to normal operation.